

Plan View

MAGELLANI DESIGNS



20'



MAGELLANI DESIGNS

Using You Set-up Instructions:

The Visionary Designs Set-up Instructions for Magellan displays are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display and a logical series of detailed steps for assembly. We encourage you to study the instructions **before** attempting to assemble your exhibit.

THIS IS VERY IMPORTANT!

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in red).

Cleaning & Packing Your Display:

- 1) Use care when cleaning aluminum extrusions or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or counter tops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing materials. It will make re-packing much easier and will reduce the likelihood of shipping damage.

Hex Key Tool



Most visionary design exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.


Typical Connection



Typical Connection




Detail A: Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.



Detail B: Each extrusion contains a numbered label that corresponds to set-up instructions. The label is located within a groove of the extrusion (when possible). Visionary Design labels contain Black numbers unless otherwise specified.

Horizontal Connection



Detail C: A rectangular connection bar with plastic T Knobs is inserted between two horizontal extrusions joined end-to-end. Turn the knobs clockwise to tighten.


Do Not Overtighten.

866.652.2100 Part Number Qty Description Base Plate Pressure Screw 48.115" Lower Curved Extrusion Note: Extrusions 5/5a and 4/4a 48.115" Upper Curved Extrusion must stay assembled when shipping. 47"h Lower Vertical Extrusion 5 47"h Upper Vertical Extrusion Velcro attched to LOWER 6a/6b 52.476" Horizontal Curved Extrusion 1/1 back of extrusion bar Connection 7a/7b 1/1 52.476" Horizontal Curved Extrusion Holes for Header Attachment Example of Pressure Screw Attachment 7a Steps: 7b 1) Attach vertical extrusions to base plates [2 to 1 and 4 to 1]. Slide Connection Bar 5a 2) Connect vertical pieces together [2 to 3 and 4/4a to 5/5a]. 5 between Extrusions 3) Connect curved extrusions together [6a to 6b and 7a to 7b]. and tighten Knobs 4) Attach horizontal assembles [6a/6b and 7a/7b] between to secure. Pressure Screw Connection Bar **GREEN STAR indicates Graphic Attachment** location of connection Apply graphics to back lock with knob. of assembled backwall. **STAR** indicates location of connection bar Note: V10 Detail with knobs on BACKSIDE of unit. Slide V10 in between Connection grooves of extrusions #5 and 5a. Rear View of Display 4a Tighten to secure. Base Plate Attachment Connection Velcro attched to UPPER Bar back of extrusion bar Turn Knob Clockwise 6a to Tighten Lock

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


Do not over tighten Knobs.

Connect Vertical Extrusion to Base Plate by placing lock into slot and tighten with tool.





866.652.2100





866.652.2100

tem	Qty.	Description
15	1	37.50"h Vertical Extrusion
16	1	37.50"h Vertical Extrusion
16A	1	Door Stop
17	1	37.50"h Vertical Extrusion
18	1	37.50"h Vertical Extrusion
19	2	Horizontal Extrusion w/ Lip
20	2	Horizontal Extrusion
21	4	Curved Horizontal Extrusion


Steps


- 1) Connect lower horizontal extrusions [19 and 21] between vertical extrusions [15, 16, 17 and 18] as shown.
- 2) Place inserts and attach door where indicated.
- 3) Attach upper horizontal extrusions [20 and 21] between vertical extrusions [15, 16, 17 and 18] and atop inserts and door.
- 4) Place shelf atop lip of extrusions [19].
- 5) Set counter top on assembled pedestal.







Backwall Components











Slip Sheet


Backwall Components cont'd








Level 2


MOD-1235 Components











MOD-1235 Components

